




V2 WIRELESS SPEAKER MANUAL




INTRODUCTION





HOW TO CONNECT









Connect to your device Setting>Bluetooth>Choose device >JUICEBOX Connected successful Blue indicator steddily on

FUNCTIONS



Note: short press the Mode switch button, to switch between Bluetooth \ TF card \ Aux-in.

OTHER



Note: Your speaker will power o automatically within 15 minutes if you did not pair it with playback devices in order to save energy.

SPECIFICATIONS


Driver speec	Φ40mm 4Ω/4W	
Size	L149.5*W48.5*H70.5 mm	
Net weight	273g	
RMS	3W x 2	
Frequency response	100HZ - 16KHZ	
Sensitivity	80db	
S/N ratio	≥70db	
Distortion	≤0.1% @1W	
Working distance	about 33 feet	
Transmission power	Class2 Class2, 4dbm	
Bluetooth profiles	A2DP,AVRCP,HFP	
Frequency range	2.400-2.480GHz	
Working current	≤600mA	
Working voltage	3.7V	
Charging voltage	DC 5V	
Charging current	500MA	

WARRANTY POLICY

Your Bluetooth speaker is covered by a limited warranty. It is backed by 1 year performance warranty against any manufacturing defects in material or workmanship from the date of original purchase. This warranty entitles the purchaser to get the product repaired or replaced under the following conditions:

- $\blacklozenge \mbox{The warranty applies to the original purchaser, Proof of original purchase is required$
- $lack ag{The warranty does not cover the damage caused by misuse, abuse or improper storage.}$
- $\blacklozenge \text{In no event shall Gsou be responsible for any direct, incidental, consequential or other damages of any kind.}$

CONTAIN



CONTACT US

JuicEBitz A/V LTD. Registered Office: Rowan House West Bank Scarborough contact.us@juicebitz.co.uk Visit us on the web www.juicebitz.co.uk Sales, support and helpline Call 0844 682 1800



WARNING

